



Efficient and stable operation | High-precision processing effect Sealed and dust-proof / Intelligent reminder



Aidite

Aidite (Qinhuangdao) Technology Co.,Ltd. Tel:0086-335-8587898 Fax: 0086-335-8587198 Email: info@aidite.com Web: www.aidite.com



AMD-500S Five-axis milling machine


Aidite AMD-500S is a high-precision, high-efficiency five-axis dry milling machine with stable operation, powerful functions and easy operation. 90° vertical processing, intelligent maintenance reminder, safety door function, integrated silicone seal and dust-proof design, bring you the most ideal processing solution.



| Platform | Aviation Aluminum Casting Structure |
|-----------------------------------|--|
| Size | 590x730x820mm |
| Weight | 180kg |
| Number of axes | 5-axis Linkage Zirconia Milling Machine |
| Processing type | Single Crown, Bridges, Veneers, Inlays, Abutments, Screw-retained Crowns, Screw-retained Bridges (Implantation Needs To Add A Separate Nesting Module) |
| Processing methods | Dry Milling |
| Processing material | Zirconia, PMMA, Wax, And Other Dry-milling Dental Soft Materials |
| Processing material thickness | 10-30mm |
| Repeatability | ± 5μm |
| Linear drive system | Linear Guide And Screw |
| Rotary drive system | Harmonic Reducer |
| Control System | Embedded Cnc System And AC Bus Servo Motor |
| Automatic tool change quantity | 10 Pieces |
| 90° buccal processing | Support |
| Safety door | Support |
| Travel | XYZ Axis: 180x110x100(mm) BA Axis: B: +30°, -90°; A: ±360° |
| Spindle | Power Consumption: AC 1500W Water Cooling Speed: 60000rpm Chuck Size: Ф4 Mm |
| Power supply | Single-phase AC 220V 50/60hz Voltage |
| Power consumption | 1.6kw 8A |
| Pressure | 6bar |

Detail Effect

vertical processing function can realize the can realize the best 3 dimensional effects in the area, and the C-shaped fixture design increases the utilization rate of materials.







Tool Life Management

· Real-time recording of tool life Smart reminder to change tools ·Bur diameter: 2.0 1.0 0.6 1.5 0.3mm

Detail Effect



High precision lead screw

· Accurate and more stable control, better tooth surface effect



漩

One-piece Silicone Dust-proof



· Effectively prevent dust from entering the interior of the equipment · Ensure efficient and stable operation of equipment

Status indication tri-color light



·Three colors distinguish the working status, making it easier to observe the operation of the equipment



Aidite

Spindle



- · Maximum speed: 60000RPM
- ·Shank diameter: 4mm
- · Power consumption: AC 1500W





·XYZ Axis: 180x110x100(mm) BA Axis: B: +30°, -90°; A: ±360° · Realize 90° vertical processing on the buccal side of the anterior teeth

Modular structure design

· Efficient and easy to maintain



Harmonic drive

· Harmonic drive to ensure high precision of milling machine