Aidite AMW-400S

AMW-400S

Efficient and stable operation | High-precision processing | Bur monitoring



Aidite

Aidite (Qinhuangdao) Technology Co.,Ltd. Tel: 0086-335-8587898

Tel: 0086-335-8587898 Fax: 0086-335-8587198 Email: info@aidite.com Web: www.aidite.com



AMW-400S 4-Axis milling machine

Aidite AMW-400S is a stable, high-precision, high-efficient wet milling machine. The equipment is easy to operate, adopts one-piece silicone protection, and a new fixture concept design. Bring you the ideal personalized abutment and glass ceramic processing solutions



Platform	Aviation cast aluminum
Size	590×730×820 (mm)
Weight	180kg
Processing method	Wet milling
Milling tool quantity	10 Pieces
Waterproof	One-piece silicone, good waterproof and airtight
Fixture	Block material fixture/reverse gripper fixture
Machinable material thickness	6 glass ceramic, 6 premill
Processed material	Premill, glass ceramics, PMMA and other wet milling block materials
Processing type	Crown and bridge, inlay, veneer, screw-retained crown, custom abutment
Nesting CAM software	Open
Processing Angle	B Axis:360°
Motor	Bus servo and motor
Air Pressure	≥6Bar
Function	Tool life management Working Status Indicator Safe door Flow detection function 90° vertical processing
Spindle	Water cooling MAX:60000RPM AC 1500W 6mm collet
Processing time	Premill≤15min glass ceramic≤20min

Detail Effect

High-precision control and brand-new structural design offer you a stable and efficient processing experience















Detail Effect



High precision lead screw

· more stable control, better tooth surface effect



Modular structure design

· Efficient and easy to maintain



Harmonic drive

· Harmonic drive to ensure high precision of machine